



**DT750**  
**Quick Reference Card**


for DT750 phones controlled by the

**SV8100**  
**Communication Server**

Some of the features described in this Quick Reference Card might require additional programming in the Communication Server. For detailed information please consult the comprehensive User Guide available at: [www.nec-unified.com](http://www.nec-unified.com).




© NEC Unified Solutions 2010  
All rights are reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.  
All brand names and product names in this document are trademarks or registered trademarks of their respective companies.



1. **Security Button** - Allows the user to block the terminal, preventing information leaks.
2. **Call Indicator Lamp** - This lamp flashes when a call terminates to the terminal and lights steadily when a message is available.
3. **LCD** – Color touch panel LCD. The screen consists of the following three information areas:

- (a) **Icon Area**
- (b) **DESI Less Information Area**



- (c) **Time/Feature Activity Information Area**
- (a) **Icon Area** - In this area you will see notifications when events occur (such as missed calls)

- (b) **DESI Less Information Area** – Provides information of the 32 Programmable Keys.
- (c) **Time/Feature Activity Information Area** – Time Display and information on various feature activities. Also Soft Keys information.
4. **Exit** - This key allows you to exit from the Menu or Help mode and go back to the main screen.
5. **Soft Keys** The Soft Keys show the available features for your current activity. Any feature shown at the bottom of the LCD is available.
6. **Help** - Press this key to display information about the Soft Keys that are in the current LCD display.
7. **Recall** - Press key to finish the call and hear the dial tone.
8. **Feature** - Used to activate any features and to program One-Touch Speed Dial Keys.
9. **Answer** - When the LED is ON, press the key to answer a waiting call.
10. **Mic** - Press this key to mute the microphone: the LED is OFF. Press the key again to un-mute the microphone. Be aware that this key is only for the hands-free microphone and does not have any effect on the headset.
11. **Menu** - Press this key to access the functions which are used now and then (such as terminal settings).
12. **Cursor Key** - Use this key to access various features with simple operation.
  - Scroll UP key
  - Volume (UP) key
  - LEFT key
  - Redial Key
  - Enter key
  - Shortcut key
  - RIGHT key
  - Directory key
  - Scroll DOWN key
  - Volume (DOWN) key
13. **Speaker** - Controls the built-in speaker which can be used for Hands Free dialing/monitoring.
14. **Transfer** - Allows the station user to transfer established calls to another station.
15. **Hold** - Places current call on hold. To resume the held call, press the Line Key. During a held call, you can dial another party by selecting a New Flexible Line Key which provides dial tone.

## BASIC SETTINGS

### To adjust handset volume

Press the Scroll UP / DOWN key in the off-hook status or during a call.

### To adjust speaker volume

Press the Scroll UP / DOWN key during speaker phone operation, or during a call that is being played on the speaker.

### To adjust ring tone volume

Press the Scroll UP / DOWN key during ringing.

### To adjust LCD contrast

Press the Scroll UP / DOWN key when in idle mode to adjust the LCD contrast.

## MAKING CALLS

1. Lift the handset or press the Speaker key to receive dial tone.
2. Enter the telephone number of the required party.

## CONFERENCE CALLS

1. While on a call, press the CONF soft key.
2. Dial desired number.
3. After call is answered, press the ADD Soft key
4. To begin conference, press the BEGIN soft key
5. Three-way conference is established.

## TRANSFERRING CALLS

1. While on a call press the Transfer key.
2. Dial destination telephone, hang up or wait for answer.

## CALL HISTORY

### To view information about Outgoing Calls (REDIAL) and Incoming Calls (CID) on your telephone

1. Press the LIST soft key.
2. Press the REDIAL Soft Key to view Outgoing Calls or the CID Soft Key to view Incoming Calls
3. Press the UP/DOWN keys to go through the list.

## DIRECTORY DIALLING

1. Press DIR Soft Key.
2. Press Soft Key for Directory Dialling type:  
ABB = Common Abbreviated Dialling.  
EXT. = Co-worker's extension numbers.  
STA. = Personal abdiads (1-10).  
TelBK = Telephone book data.
3. Dial letter/number range for the party you want to call (e.g., dial 2 for A, B, C or 2).
4. Press the Down Arrow Soft Key to jump to that section.
5. Press Up or Down Arrow Soft Key to scroll through the list.
6. Press SPEAKER key or lift handset to place call or press DIAL soft key

## FUNCTION KEYS

One or more Programmable Keys can be pre-programmed with a dedicated function or a telephone number.

Ask your system administrator for more details.

### Function

Ask your system administrator for more details.

## STANDARD FEATURE CODES

The following list of feature codes might require additional programming in the Communication Server. Please contact your system administrator for more details.

9	Outside Number
810	Break In / Executive override
850	Call Back set
850	Start Call Waiting
848	Call Forwarding-All Calls set
8480	Call Forwarding-All Calls cancel
843	Call Forwarding-Busy set
8430	Call Forwarding-Busy cancel
845	Call Forwarding-Don't Answer set
8450	Call Forwarding-Don't Answer cancel
844	Call Forwarding (No answer & Busy) set
8440	Call Forwarding (No answer & Busy) cancel
870	Call Back cancel
847	Do Not Disturb set
8470	Do Not Disturb cancel
841	Message Waiting Lamp Control set
871	Message Waiting Lamp Control Cancel